

Tuff Torque™ Spiral Screw Extractors

Once the center of the broken stud has been drilled out, use the Tuff Torque™ Spiral Screw Extractors to quickly remove the stud. The spiral edge increases surface tension during extraction for improved back out strength.



999-0-0065



999-0-0069



999-0-0070



999-6-1805



999-6-1810



999-6-1820

Code #	Extractor Number	To Remove	Drill Size
805-0-1001	1	3/32-5/32	5/64
805-0-1002	2	5/32-7/32	7/64
805-0-1003	3	7/32-9/32	5/32
805-0-1004	4	9/32-3/8	1/4
805-0-1005	5	3/8-5/8	17/64
805-0-1006	6	5/8-7/8 3/8 Pipe	13/32
805-0-1007	7	7/8 - 1-1/8 1/2 Pipe	17/32
805-0-1008	8	1-1/8 - 1-3/8 3/4 Pipe	13/16
805-0-1009	9	1-3/8 up 1" Pipe	1-1/8

Assortments

- 999-0-0065 5 piece Tuff Torque™ assortment in pouch
1 each - 1, 2, 3, 4, 5
- 999-0-0069 9 piece Tuff Torque™ assortment in pouch
#1 through #9
- 999-0-0070 10 piece Tuff Torque™ assortment in pouch
1 each - 1, 2, 3, 4, 5 with 5 drill bits, 5/64", 7/64", 5/32", 1/4", 17/64"
- 999-6-1805 1 ea. Left Hand Cryobits® in plastic tray –
5/64", 7/64", 5/32", 1/4", 17/64" with Spiral Screw Extractor #1, #2, #3, #4, and #5
- 999-6-1810 1 ea. Cryobits in screw extractor index – 5/64", 7/64", 5/32", 1/4", 17/64" with Spiral Screw Extractor #1, #2, #3, #4, and #5
- 999-6-1820 1 ea. Left Hand Cryobits® in screw extractor index – 5/64", 7/64", 5/32", 1/4", 17/64" with Spiral Screw Extractor #1, #2, #3, #4, and #5

SPECIFICATIONS

Material AISI 1095 tempered steel
 Hardness 54-58 Rc



Available in select sizes only



Scan to see video!